


Fall Clearance Chart*

***Diagram shown is an example fall clearance calculation ONLY.

***Calculations are based on SRD anchored above head

For all applications: worker weight capacity range (including all clothing, tools, and equipment) is 130-310 lbs



*Guidelines provided are not all-encompassing. Please refer to product instruction manual(s) and training materials for full inspection checklists.

Copyright © 2018 SAFEWAZE. All rights reserved.



800.239.0310

info@safewaze.com

www.safewaze.com