



INSTALLATION / USAGE INSTRUCTIONS



Remove Cotter Pin, Retaining Pin, Pulley Housing, and Pulley from the top of tripod.



(Top of tripod with pulleys removed)

Replace removed assembly with FS970-PK