



SAFEWAZE



SHIPPING LOCK NOTICE

The Northstar Edge and Coastal Edge are equipped with retraction limiters, it is still possible to lock the pawls during transportation or use. This is due to the elongated pawls, which provide these devices with added security when being used on flexible anchor points such as Horizontal Lifelines.

HOW TO RELEASE LOCKED CABLE

If the lifeline will not extend:

- 1** Place the SRL on the ground with the cable side facing down to keep the unit properly aligned.
- 2** Tilt the SRL and hold the lifeline handle firmly with one hand.
- 3** Using your other hand, push the lifeline back into the housing. The handle is spring-loaded and will allow slight inward movement. This inward movement will disengage the internal pawls.
- 4** Once released, slowly pull the lifeline out in a smooth, controlled motion to resume normal operation.

WHY THIS HAPPENS

The Northstar SRL uses a highly responsive pawl system designed to engage quickly during sudden movement. This same feature that ensures rapid fall arrest can occasionally activate during transit.

WATCH HOW TO RESET

Scan the QR code below for a quick video demonstration.



Engineered for fast engagement and reliable fall protection when it matters most.



225 Wilshire Avenue SW, Concord NC 28025
800-230-0319 • safewaze.com

