



Detailed video available at [safewaze.com](http://safewaze.com)!

### HARNES INSTALLATION:

Confirm that you have both 'A' and 'B' Arc Flash Trauma Straps packs.  
Packs A and B can attach on either hip. Install pack A on your dominant side.

<b>A:</b> Place pack A with the letter facing right side up on the torso webbing loop that contains the leg strap. Open the pack to expose three Velcro flaps.	<b>B:</b> On the side with two flaps, insert the inside flap fully in the web loop.	<b>C:</b> Fold the flap on the opposite side over the first flap and press to secure.	<b>D:</b> Fold the remaining flap over the first two flaps, pressing firmly together. Repeat steps A-D with pack B on the other side of the harness.	<b>E:</b> Inspect both packs. Tug to confirm both packs are securely attached. <b>WARNING</b> Safewaze Logo and Trauma Relief Label must face leg buckles of harness.

### TRAUMA RELIEF - DEPLOYMENT AND USE:

<b>1:</b> Pull yellow tabs up to release pack.	<b>2:</b> Place thumbs through red elastic rings and begin to pull webbing out.	<b>3:</b> Pull webbing fully out of packs and maintain hold of both ends of webbing. See 3A-3C below to connect the ends.	<b>4:</b> Place feet into webbing straps while maintaining hold of the webbing handle.	<b>5:</b> Pull webbing handle to tighten the webbing strap to relieve pressure on the legs.

### MAKING THE HOOK CONNECTION:

<b>3A:</b> Maintain a hold of red elastic rings. Raise the ends of the straps to identify hook and soft loop.	<b>3B:</b> Insert hook into soft loop slot at the end of the webbing fully. <b>DO NOT HOOK ON THE RED ELASTIC RING.</b>	<b>3C:</b> Tug lightly on webbing to confirm hook is secure. Drop end without the hook ('B') and maintain hold of the webbing handle ('A') near the end with the hook.

**Note:** The product will not be exactly as pictured due to its arc flash features.