



SAFEWAZE

024-4115 (Steel) & 025-4126 (Nylon)

Standing Seam Bar Anchor Manual



STANDARDS	
ANSI	N/A
OSHA	1926.502, 1910.140, 1910.66

This manual intends to meet the Manufacturer's Instructions specified by the American National Standards Institute (ANSI) and should be utilized as part of an employee training program as required by the Occupational Safety and Health Administration (OSHA).

**Read and understand instructions before using equipment!
Do not throw away instructions!**

**Always verify the latest revision of the Safewaze Manual is being utilized.
Visit the Safewaze website, or contact Customer Service, for updated manuals.**

⚠ IMPORTANT:

- Please refer to this manual for essential instructions on the use, care, or suitability of this equipment for your application. Contact Safewaze for any additional questions.
- Record all important product information prior to use. Documentation of all Competent Person annual inspections is required in the Inspection Log.

▶ USER INFORMATION

Date of First Use: _____

Serial Number: _____

Trainer: _____

User: _____

▶ SAFETY INFORMATION AND PRECAUTIONS

- The manufacturer's instructions must be provided to users of this equipment.
- The user must read, understand, and follow all safety and usage information contained within this manual.
- The user must safely and effectively use the product and all equipment used in conjunction with the product.
- Failure to follow all safety and usage information can result in serious injury or death.

⚠Warnings:

Regulations included herein are not all-inclusive, are for reference only, and are not intended to replace a Competent Person's judgment or knowledge of federal or state standards.

The warnings indicated below are designed to minimize risk associated with the use of the Standing Seam Bar Anchor.

- Users should consult with their doctor to verify ability to safely absorb the forces of a fall arrest event. Fitness level, age, and other health conditions can greatly affect an individual's ability to withstand fall arrest forces. Women who are pregnant and individuals considered minors must not use any Safewaze equipment.
- Do not alter or misuse equipment. Only Safewaze, or entities authorized in writing by Safewaze, may make repairs to Safewaze fall protection equipment.
- A Competent Person must conduct an analysis of the workplace and anticipate where workers will be conducting their duties, the route they will take to reach their work, and any existing and potential fall hazards. The Competent Person must choose the fall protection equipment to be utilized. Selections must account for all potential hazardous workplace conditions. All fall protection equipment should be purchased in new and unused condition.
- If work is conducted in a high heat environment, ensure that Arc Flash or other suitable fall protection equipment is utilized.
- Use of a body belt is not authorized for fall arrest applications.
- Work directly under the anchor point as much as possible to minimize swing fall hazards.
- The user must ensure that there is adequate fall clearance when working at height.
- Anchors that are exposed to fall arrest forces must be immediately removed from service and destroyed.
- Training of Authorized Persons to correctly install, inspect, disassemble, maintain, store, and use equipment must be provided by a Competent Person. Training must include the ability to recognize fall hazards, minimize the likelihood of fall hazards, and the correct use of personal fall arrest systems.
- If conducting training operations with this equipment, a secondary fall protection system must be installed and utilized to ensure the trainee is not exposed to unintended fall hazards.
- Equipment designated for fall protection must never be used to lift, hang, support, or hoist tools or equipment unless specifically certified for such use.
- Avoid using the anchor in applications where engulfment hazards exist.
- Avoid moving machinery, sharp and/or abrasive edges, and any other hazard that could damage or degrade the component.
- Utilize extra caution to keep lifeline free from any obstructions including, but not limited to, surrounding objects, tools, equipment, moving machinery, co-workers, yourself, or possible impact from overhead objects.
- Ensure the roof sheathing is secured to a structural member that is capable of sustaining static loads required by this product prior to attachment.
- Only use fasteners approved by Safewaze for use with this device.
- Always verify the device seam clamps are compatible with the roof seam.
- Do not mount to tapered surfaces (e.g. S-beams).

TABLE OF CONTENTS

1.0 ▶ Introduction	5
2.0 ▶ Intended Use	5
3.0 ▶ Applicable Safety Standards	5
4.0 ▶ Worker Classifications	5
5.0 ▶ Rescue Plan	6
6.0 ▶ Product Limitations	6
7.0 ▶ Allowed Anchorage Applications	7
8.0 ▶ Product Specifications	8
9.0 ▶ Fall Clearance	8
10.0 ▶ Compatibility of Connectors	11
11.0 ▶ Making Connections	11
12.0 ▶ Prior to Installing the Anchor	12
13.0 ▶ Installation of Anchor	13
14.0 ▶ Inspection	15
15.0 ▶ Maintenance	17
16.0 ▶ Labels	17
17.0 ▶ Standing Seam Information	18
18.0 ▶ Annual Inspection Form	24

► 1.0 INTRODUCTION

Thank you for purchasing a Safewaze Standing Seam Bar Anchor. This manual must be read and understood in its entirety and used as part of an employee training program as required by OSHA or any applicable state agency.

This easy to install, reusable anchor is designed for installation on a flat or sloped standing seam roof with a minimum gauge of 26 or on ¼"-1" (6 mm- 25 mm) thick steel plates, beams, and angle iron. The Standing Seam Bar Anchor acts as a single anchorage connector for fall protection equipment and can be used with Energy Absorbing Lanyards, Vertical Lifelines (VLLs), and Self-Retracting Lifelines (SRLs). The anchor can be used for Horizontal Lifeline (HLL) use ONLY if installed on steel plates, beams, or angle iron. The anchor cannot be used for HLL use on Standing Seams. The anchor is not suitable for material hauling use.

► 2.0 INTENDED USE

The equipment covered in this manual is intended for use as part of a complete personal fall protection system. Use of this equipment for any other purpose including, but not limited to, sports or recreational activities, non-approved material handling applications, or other action not described in these instructions, is not approved by Safewaze.

Use of this equipment in a manner outside the scope of those covered within this manual can result in serious injury or death. The equipment covered in this manual must only be used by trained personnel in workplace applications. If the anchor is used for training, a secondary fall protection system must be used so the trainee is not exposed to accidental fall hazards.

► 3.0 APPLICABLE SAFETY STANDARDS

When used according to instructions, this product meets **OSHA 1926.502, 1910.140, and 1910.66** regulations. Applicable standards and regulations depend on the type of work being done and may include state-specific regulations.

Refer to local, state, and federal requirements for additional information on the governing of occupational safety regarding Personal Fall Arrest Systems (PFAS).

► 4.0 WORKER CLASSIFICATIONS

Read and understand the definitions of those who work in proximity of, or may be exposed to, fall hazards:

Qualified Engineer: A person with a Bachelor of Science in Engineering degree from an accredited college or university. They are able to assume personal responsibility for the development and application of engineering science and knowledge in the design, construction, use, and maintenance of their projects.

Qualified Person: One who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training, and experience, has successfully demonstrated their ability to solve or resolve problems relating to the subject matter, the work, or the project.

Competent Person: One who is capable of identifying existing and predictable hazards in the surroundings or working conditions which are unsanitary, hazardous, or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate them.

Authorized Person: A person approved or assigned by the employer to perform a specific type of duty or duties, or to be at a specific location or locations, at the jobsite.

It is the responsibility of a Qualified Person or Engineer to supervise the jobsite and ensure safety regulations are met.

► 5.0 RESCUE PLAN

Prior to the use of this equipment, employers must create a rescue plan in the event of a fall and provide the means to implement the plan through training. The rescue plan must be specific to the project. The rescue plan must allow for employees to rescue themselves or be promptly rescued by alternative means.

This plan must be communicated to/understood by all equipment users, authorized persons, and rescuers. Rescue operations may require specialized equipment beyond the scope of this manual. Every user must be trained in the inspection, installation, operation, and proper usage of their Rescue Equipment and Rescue Plan. See ANSI Z359.4-2013 for specific rescue information. Immediately seek medical attention in the event a worker suffers a fall arrest incident.

Note: Special rescue measures may be required for a fall over an edge.

► 6.0 PRODUCT LIMITATIONS

When installing or using this equipment always refer to the following requirements and limitations:

- **Capacity Range:** ANSI 130-310 lbs. (59-141 kg) and OSHA up to 420 lbs. (191 kg). *including clothing, tools, equipment, etc.
- **Anchorage:** Anchorages selected for fall arrest systems shall have a strength capable of sustaining static loads applied in the directions permitted by the system of at least:
 1. 5,000 lbs. (2267.9 kg) for non-certified anchorages, or
 2. Two times the maximum arresting force for certified anchorages.
 3. 3,100 lbs. for Rescue applications.

When more than one fall arrest system is attached to an anchorage, the strengths set forth in one of the above shall be multiplied by the number of systems attached to the anchorage.

From OSHA 1926.502 and 1910.66: Anchorages used for attachment of personal fall arrest systems shall be independent of any anchorage being used to support or suspend platforms and capable of supporting at least 5,000 lbs. (2267.9 kg) per user attached. Or, anchorages for attachment should be designed, installed, and used as part of a complete PFAS which maintains a safety factor of at least two and is under the supervision of a Qualified Person.

- **Locking Speed:** The nature of this equipment requires a clear fall path to ensure the SRL will lock in the event of a fall. Working in obstructed fall paths, cramped areas, or on moving materials like sand and grain, may not allow the user's body to gain enough speed buildup to cause the SRL to engage and lock in the event of a fall.
- **Free Fall:** The maximum allowable free fall is 6 feet. Limit free fall distance by keeping anchorage in-line with work area.
- **Swing Falls:** As the user moves laterally away from an overhead anchor point, the risks related to swing falls increase. The force of striking an object involving swing fall can in some instances generate more forces than a fall with the user wearing no fall protection equipment. Minimize swing falls by working as directly below the anchorage point as possible.
- **Fall Clearance:** Fall Clearance (FC) is the total combined values of the Rope Elongation, Lanyard Length, Deceleration Distance, Harness Stretch, Height of Worker, and Safety Factor. Safewaze uses a 2 ft. Safety Factor. The Safety Factor includes fall arrester slippage. Refer to the chosen PFAS system product manual when calculating fall clearance.

Additional Fall Clearance is required for falls from a kneeling or crouched position. If a Swing Fall hazard exists, the total vertical fall distance will be greater than if the user had fallen directly under the anchor point. This manual provides information regarding Swing Fall hazards and additional Fall Clearance Requirements in Section 9.

- **Hazards:** Extra precautions should be taken if this equipment is used in an environment where hazards exist. Hazards can include, but are not limited to, moving machinery, high voltage equipment or power lines, caustic chemicals, corrosive environments, toxic or explosive gases, or high heat. Avoid working in an area where overhead equipment or personnel could fall and contact the user, fall protection equipment, or the lifeline. Areas where the user's lifeline may cross or tangle with the lifeline of another user should be avoided. Do not allow the lifeline to pass under arms or between the legs.
- **Sharp Edges:** Safewaze Class 2 SRLs are designed for use in both Overhead and Leading Edge Environments. Should a specific work area have extremely sharp edge(s) that may come into contact with the lifeline constituent of the SRL, a Class 2 SRL is required.

▶ 7.0 ALLOWED ANCHORAGE APPLICATIONS

Personal Fall Arrest: Safewaze Anchors are designed as an anchor point to support a maximum of 1 PFAS when utilized for fall protection applications. The structure to which the anchor is attached must withstand loads applied in the directions permitted by the system of at least 5,000 lbs. (22 kN) or be designed with a safety factor of two to one. Maximum allowable free fall is based on the connector used.



Restraint: Safewaze Anchors are authorized for use in Restraint applications. The structure to which the anchor is attached must withstand loads applied in the directions permitted by the system of at least 1,000 lbs. NO free fall is permitted. Restraint systems may only be used on surfaces with slopes up to 4/12 (vertical/horizontal). For Restraint applications, the allowable attachment points to the harness are Dorsal, Front/Sternal, Side, and Shoulder D-rings.



Work Positioning: Safewaze Anchors are authorized for use in Work Positioning applications. Work Positioning allows a worker to be supported during suspension while freeing both hands to conduct work operations. The structure to which the Anchor is attached must withstand loads applied in the directions permitted by the system of at least 3,000 lbs. Maximum allowable free fall is 2 ft. For positioning applications, the allowable attachment points to the harness are the Side D-rings.



Rescue/Confined Space: Safewaze Anchors are authorized for use in Rescue/Confined Space applications. Rescue systems are utilized to safely recover a worker from a confined location or after exposure to a fall. Composition of rescue systems can vary based upon the type of rescue involved. The structure to which the anchor is attached must withstand loads applied in the directions permitted by the system of at least 3,100 lbs. NO free fall is permitted for rescue scenarios. For confined space scenarios, maximum allowable free fall is based on the PFAS used. For these applications, the allowable attachment points to the harness are Dorsal, Front/Sternal, and Shoulder D-rings.



► 8.0 PRODUCT SPECIFICATIONS

- Capacity: 1 user, ANSI 130-310 lbs. (59-141 kg) and OSHA up to 420 lbs. (191 kg). *including clothing, tools, equipment, etc.
- Temporary, reusable, and non-penetrating Single Point Anchorage Connector with 360° Swivel D-ring.
- Materials: Anchor (Aluminum), D-ring (Stainless Steel), Label Cover (Polyester)
- Minimum Breaking Strength (MBS):
 - » Standing Seams: 5,000 lbs. (22kN) when direction of use is parallel with seam or 3,600 lbs. (16 kN) for 360° use.
 - » Steel Plates, Beams, and Angle Iron: 5,000 lbs. (22kN) in all directions.
- Item Weight: 3 lbs. (1.4 kg)
- Installation Location:
 - » Standing Seam Roof Gauge: Minimum 26 roof gauge required for installation of anchor.
 - » Steel Plates, Beams, and Angle Iron Specifications: Must be ¼"-1" (6 mm-25 mm) thick.
- Includes: (12) stainless steel set screws with 024-4115 or 12 stainless steel set screws with nylon tips with 025-4126
- Related Products:
 - » (12) Standing Seam Nylon-Tipped Set Screws (025-4127)
 - » (12) Standing Seam Steel Set Screws (025-4128)

► 9.0 FALL CLEARANCE


Always select an SRL/lanyard and anchor point location that limits free fall and swing fall as much as possible. Refer to the chosen PFAS system manuals for information on fall clearance. A free fall of more than 6 ft. could cause excessive arrest forces that could result in serious injury or death.

- **Fall Clearance:** There must be sufficient clearance below the anchorage connector to arrest a fall before the user strikes the ground or an obstruction. When calculating fall clearance, account for all applicable factors. A Competent Person must reference the entire system's components to calculate Fall Clearance.


THE FOLLOWING DIAGRAMS ARE EXAMPLES ONLY.

Note: Numbers used in these examples are based on ZERO offset and setback with the anchor directly overhead or below, to represent an in-line Fall Clearance calculation. Consult with a Competent Person when working in different scenarios and when using non-Safewaze equipment.



6' FREE FALL LANYARD (OVERHEAD) EXAMPLE




12' FREE FALL LANYARD (BELOW D-RING) EXAMPLE



CLASS 1 (OVERHEAD) EXAMPLE


		6' HEIGHT OF ANCHOR		
13' REQUIRED CLEARANCE FROM ANCHOR	0' FREE FALL			
	7' REQUIRED CLEARANCE FROM WORKING SURFACE			
			ARREST DISTANCE 42" MAX. PER ANSI Z359.14-2021 CLASS 1	3.5'
			HARNES STRETCH 18" MAX. PER ANSI Z359.11-2021	1.5'
			SAFETY FACTOR	2'
		SWING FALL DROP DISTANCE		TBD

CLASS 2 (BELOW D-RING) EXAMPLE

		0' HEIGHT OF ANCHOR		5' FREE FALL	
		WORKING SURFACE			
		ARREST DISTANCE REFER TO MANUAL FOR PUBLISHED ARREST DISTANCES PER ANSI Z359.14-2021 CLASS 2	8'	16.5' REQUIRED CLEARANCE FROM WORKING SURFACE	16.5' REQUIRED CLEARANCE FROM ANCHOR
		HARNES STRETCH 18" MAX. PER ANSI Z359.11-2021	1.5'		
		HEIGHT OF WORKER WORKING SURFACE TO DORSAL D-RING	5'		
		SAFETY FACTOR	2'		
		SWING FALL DROP DISTANCE			

- **Swing Falls:** Prior to installation or use, make considerations for eliminating or minimizing all swing fall hazards. Swing falls occur when the anchor is not directly above the location where a fall occurs. Always work as close to, or in line with, the anchor point as possible. Swing falls significantly increase the likelihood of serious injury or death in the event of a fall. Ensure a Competent Person includes swing fall in calculations if the hazard exists.


SWING FALL:



► 10.0 COMPATIBILITY OF CONNECTORS

- Safewaze equipment is designed for, and tested with, associated Safewaze components or systems. If substitutions or replacements are made, ensure all components meet the applicable ANSI requirements. Read and follow manufacturer's instructions for all components and subsystems in your PFAS. Not following this guidance may jeopardize compatibility of equipment and possibly affect the safety and reliability of the system.
- Connectors are compatible with connecting elements when they have been designed to work together in such a way that their sizes and shapes do not cause their gate mechanisms to inadvertently open regardless of how they become oriented.
- Connectors (hooks, carabiners, and D-rings) must be capable of supporting at least 5,000 lbs. (22 kN).
- Connectors must be compatible with the anchorage or other system components.
- Do not use equipment that is not compatible. Non-compatible connectors may unintentionally disengage.
- Connectors must be compatible in size, shape, and strength.
- Self-locking snap hooks and carabiners are required by OSHA guidelines.
- Some specialty connectors have additional requirements. Contact Safewaze if you have any questions about compatibility.

UNINTENTIONAL DISENGAGEMENT:



Using a connector that is undersized or irregular in shape (1) to connect a snap hook or carabiner could allow the connector to force open the gate of the snap hook or carabiner. When force is applied, the gate of the hook or carabiner presses against the non-compliant part (2) and forces open the gate (3). This allows the snap hook or carabiner to disengage (4) from the connection point.


► 11.0 MAKING CONNECTIONS

Snap hooks and carabiners used with this equipment must be double locking and/ or twist lock. Ensure all connections are compatible in size, shape, and strength. Do not use equipment that is not compatible. Ensure all connectors are fully closed and locked.

Safewaze connectors (hooks, carabiners, and D-rings) are designed to be used only as specified in each product's manual. See figure below for examples of inappropriate connections. Do not connect snap hooks and carabiners:

- To a D-ring to which another connector is attached.
- In a manner that would result in a load on the gate (with the exception of tie-back hooks).
- In a false engagement, where features that protrude from the snap hook or carabiner catch on the anchor, and without visual confirmation seems to be fully engaged to the anchor point.
- To each other.
- By wrapping the web lifeline around an anchor and securing to lifeline, except as allowed for tie-back models.
- To any object which is shaped or sized in a way that the snap hook or carabiner will not close and lock, or that roll-out could occur.
- In a manner that does not allow the connector to align properly while under load.


INAPPROPRIATE CONNECTIONS:



Large throat snap hooks must not be connected to standard size D-rings or similar objects which will result in a load on the gate if the hook or D-ring twists or rotates, unless the snap hook complies with ANSI Z359.1-2007 or ANSI Z359.12 and is equipped with a 3,600 lb. (16 kN) gate.


► 12.0 PRIOR TO INSTALLING THE ANCHOR

Prior to the installation of the anchor, a Competent Person must determine that the installation location is capable of supporting intended loads on the anchor. Ensure that the seam profile is compatible with the anchor. The anchor must sit flush on the standing seam panel. Roofs must have a minimum panel thickness of 26-gauge, or thicker. Steel plates, beams, and angle iron must be ¼"-1" (6 mm-25 mm) thick. The anchor must be mounted to flat steel surfaces only. Tapered surfaces (e.g. S-Beams) are not permitted:



The work location should be free of debris and other materials or equipment that could interfere with the proper operation of the product. Inspect the intended installation location for hazards that include, but are not limited to, corrosion, cracking, rust staining, holes, deterioration, weathering, electrical hazards, etc. Additionally, use Figure 1 to ensure the anchor is compatible with the standing seam profile before installation.

FIGURE 1: STANDING SEAM PROFILE COMPATIBILITY DIMENSIONS



See Pages 18-24 for a noncomprehensive list of standing seam panels by make and model. Always ensure the standing seam panel dimensions and specifications are within the allowable dimensions (above) of the anchor before installation.

► 13.0 INSTALLATION OF THE STANDING SEAM BAR ANCHOR

Installation:

1. Determine if standing seam structure is compatible with the Standing Seam Bar Anchor.
2. Only nylon tipped or steel screws may be used for installation. Choose set screw type at time of purchase (024-4115 for Steel or 025-4126 for Nylon). Replacement screw part numbers are 025-4127 (Nylon Tipped) or 025-4128 (Steel).
3. Center the anchor on the roof seam. Ensure the anchor base is flush on the installation location.
4. Install all set screws in the order shown (Figure 2). Torque according to the specified value based on type of screw:
 - Steel Torque Value= 90 in.-lb.
 - Nylon Tipped Torque Value= 180 in.-lb.
5. Repeat torque sequence again (two times total).
6. Once properly installed*, the user may attach a complete and compatible PFAS to the D-ring connection point on the anchor.

***Note:** Repeat torquing process before every use.

FIGURE 2: SET SCREW INSTALLATION SEQUENCE






FIGURE 3: MBS & DIRECTION OF USE

Standing Seams:

Steel Plates, Beams, & Angle Iron:



► 14.0 INSPECTION

The user must keep instructions available for reference and record the date of first use on Page 2.

The user must immediately remove the system from service if defects or damage are found, or if exposed to forces of fall arrest.

Work Area:

- Inspect the work area to ensure the location is free of any damage including, but not limited to, debris, cracking, rot, decay, structural deterioration, rust, and any hazardous materials.
- A Competent Person must determine that the installation location to be utilized will support the intended loads.

Frequency:

- A Competent Person, other than the user, must inspect the Standing Seam Bar Anchor at least once annually.
- While conducting inspections, the Competent Person must consider all applications and hazards that the equipment may have been subjected to while in use.
- Competent Person inspections must be recorded in the Inspection Log included in this manual (Page 24), or on the inspection table labels on each product individually. The Competent Person must place their initials in the block which corresponds with the month and year that the inspection is performed. All individual labels on the equipment will be initialed in the same manner.


INSPECTION FREQUENCY:

Type of Use	Application Examples	Conditions of Use	Inspection Frequency by Competent Person
Infrequent to Light	Rescue and Confined Space, Factory Maintenance	Good Storage Conditions, Indoor or Infrequent Outdoor Use, Room Temperature, Clean Environments	Annually
Moderate to Heavy	Transportation, Residential Construction, Utilities, Warehouse	Fair Storage Conditions, Indoor and Extended Outdoor Use, All Temperatures, Clean or Dusty Environments	Semi-Annually to Annually
Severe to Continuous	Commercial Construction, Oil and Gas, Mining	Harsh Storage Conditions, Prolonged or Continuous Outdoor Use, All Temperatures, Dirty Environment	Quarterly to Semi-Annually

Directions:

- Prior to each use, inspect the anchor for possible deficiencies including, but not limited to, missing parts, corrosion, deformation, pits, burrs, rough surfaces, sharp edges, cracking, rust, paint buildup, excessive heating, alteration, and missing or illegible labels. Inspect all components of the device including the base, clamps, bolts, and setscrews.
- Prior to each use, the user must inspect and verify that each individual component (Figure 4) of the anchor is safe for use:
 1. Inspect the anchor for bending or wear.
 2. Ensure the and setscrews are present.
 3. Re-torque the setscrews.

FIGURE 4: ANCHOR COMPONENTS



D-ring	1
Anchor	2
Set Screws	3
Labels	4

▶ 15.0 MAINTENANCE

Repairs:

Only Safewaze, or entities authorized in writing by Safewaze, may make repairs to Safewaze fall protection equipment.

Cleaning:

The anchor can be cleaned with water and mild soap. The user should remove all dirt, possible corrosives, and contaminants from the system prior to, and after, each use. Never use any type of corrosive substance to clean the system.

Excess water should be blown out with compressed air. Hardware can be wiped off with a clean, dry cloth. Do not store system if wet or damp. Allow equipment to fully dry before being stored.

Storage:

Prior to installation, store the anchor in a cool, dry area where it will not be exposed to extreme light, extreme heat, excessive moisture, or possibly corrosive chemicals or materials.


Lifespan:

The working life of the anchor is determined by work conditions, care, and inspection provided. So long as the system and all components pass inspection, it may remain in service.




Disposal:

Dispose of the anchor if inspection reveals an unsafe or defective condition. If damaged and unserviceable, the system should be destroyed so as not to allow accidental re-use.

▶ 16.0 LABELS

 SAFEWAZE 225 Wilshire Ave SW Concord, NC 28026 USA (800) 236-0319 safewaze.com Serial Number: XXXXXXXX	STANDING SEAM BAR ANCHOR Materials: Aluminum, Stainless Steel Standards: OSHA 1926 502, 1910.140, 1910.66 Capacity: ANSI 130-310 lbs. (59-141 kg), OSHA up to 420 lbs. (191 kg)	⚠ WARNING: This equipment is designed for use as a fall protection anchor. Do not use for material hoisting. See manual for approved HLL use. Users must read and follow instructions supplied with this product at the time of shipment. Failure to do so may result in serious injury or death. Avoid contact with hazards including, but not limited to, heat, chemicals, electricity, and sharp/abrasive edges and surfaces. Do not alter or misuse this product. Do not remove label. Make only compatible connections. 470-00422
SEE PRODUCT MANUAL FOR ADDITIONAL WARNINGS, APPROPRIATE INSTALLATION AND CONNECTION METHODS, AND COMPLETE INSPECTION PROCEDURES.		

INSPECTION: Inspect anchor according to manufacturer's instructions prior to each use. A Competent Person must inspect anchor at least annually. If equipment fails inspection, or is exposed to fall arrest forces, IMMEDIATELY REMOVE FROM SERVICE.	INSTALLATION: <ul style="list-style-type: none"> Choose type of set screw (only nylon tipped or steel screws) Determine if standing seam structure is compatible with the anchor. Center anchor on roof seam and ensure base is flush on the installation location. Install all set screws and torque according to the specified value based on type of screw: <ul style="list-style-type: none"> Steel Torque Value= 90 in.-lb. Nylon Tipped Torque Value= 180 in.-lb. Repeat torque sequence twice. Once properly installed, attach PFAS to the anchor's D-ring connection point. 																				
INSPECTION LOG <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="writing-mode: vertical-rl; transform: rotate(180deg);">INITIAL</th> <th style="writing-mode: vertical-rl; transform: rotate(180deg);">DATE</th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	INITIAL	DATE																			470-00423
INITIAL	DATE																				

MINIMUM BREAKING STRENGTH (MBS): <ul style="list-style-type: none"> 5,000 lbs. (22 kN) when direction of use is parallel with seam. 3,600 lbs. (16 kN) for 360° use. 	STRUCTURE REQUIREMENTS: Roofs must have a minimum panel thickness of 26-gauge, or thicker. Steel plates, beams, and angle iron must be 1/4" (6 mm) - 1" (25 mm) thick. WARNING: Mount to flat steel surfaces only. Tapered surfaces not permitted (ex. S-beams).		
		470-00424	

► 17.0 STANDING SEAM INFORMATION

Disclaimer: This is a reference-only, noncomprehensive list of standing seam panels by make and model. Safewaze does not have control over the manufacturing, tolerances, specifications, and variations of these listed panels. Always verify the standing seam panel dimensions and specifications are within the allowable dimensions (Figure 1) of the anchor before installation.

<u>MANUFACTURER:</u>	<u>PANEL TYPE:</u>
A&S	BattenLok HS
A&S	SuperLok
A&S	DoubleLok
A&S	Ultra-Dek
A&S	CFR 30", 36", 42"
A&S	DuraSeal Seam/DuraSeal Snap
AB Martin Roofing	ABSeam 19.5
AB Martin Roofing	ABM 1" Nail Strip
ACI Metal Roofing	SnapLok
ACI Metal Roofing	Stratoshield
ACI Metal Roofing	UltraLok
AEP Span	Design Span hp
AEP Span	Span Lok
AEP Span	SpanSeam
AEP Span	Multilok
AEP Span	Skyline / Skyline hp
AEP Span	Snap Seam
AEP Span	Sterling Roof System
AEP Span	High Seam
Agway Metals	AR Standing Seam, NS, SL
Alcan	Snap Lock 1" and 1.5"
Alcan	Mechanical Lock 1" & 1.5"
All Weather Insulated Panels	SR Series (Single Fold)
American Buildings by Nucor	Seam-Loc
American Buildings by Nucor	Loc/Seam/Loc Seam 360
American Buildings by Nucor	Standing Seam II
American Buildings by Nucor	Standing Seam 360
American Construction Metals ACM	Kenloc, Stayloc, Mechloc
AMS-Arch. Metal Solutions	ArmorLock/SnapLock/ProLock
Architectural Building Components/McElroy	138T, 238T
Architectural Building Components/McElroy	Permaseam Interlock
Architectural Building Components/McElroy	Maxima ADV
AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc
AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc HS

MANUFACTURER:**PANEL TYPE:**

AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc Plus
ASP-Arch. Sheetmetal Prod.	SL Series/ML Series/MLC Series
ATAS	Dutch Seam
ATAS	Field-Lok FLL 1", 1.5"
Bax Steel	Bax-Lock
BC Steel Buildings	BCL-24-SD
BC Steel Buildings	BCL-24-MS
Behlen Building Systems	Roll-Lock/Triple-Lock/Quadri-Lock
Behlen Building Systems	ZL-24/Triple-Lock/Quadri-Lock
Bemo	Bemo Roof
Berridge	High Seam Tee-Panel
Berridge	Cee-Lock
Berridge	Zee-Lock
BHP	Zip Rib
Bridger Steel	Tru-Snap 1", 1.5"
Bridger Steel	Nail Strip 1" and 1.5"
Bryer Company	TBC-Ultra
Bryer Company	TBC-Superseam
Bryer Company	TBC-SuperCurve
Butler	MR-24
Butler	Genesis 360
Butler	CMR-24
Butler	VSR II
Carlisle Syntec	CM 175SL/CM 150SL Snap Lock
Carlisle Syntec	CM 200S/CM 150 SS
CBC Steel Buildings by Nucor	MS-24
CBC Steel Buildings by Nucor	SS-24
Ceco Buildings	Double-Lok
Ceco Buildings	BattenLok HS
Ceco Buildings	SuperLok
Ceco Buildings	CRP / CLP / CXP
Central States Manufacturing	Central Snap
Central States Manufacturing	Central Span
Central States Manufacturing	Central Seam Plus
Central States Manufacturing	Central Loc
Central Texas Metal Roofing Supply	ShurLoc 150
Central Texas Metal Roofing Supply	SpanLoc 100, 150
Centria	SRS-2 / SRS-3
Centria	SDP Series
Chief Buildings	MSC Panel

MANUFACTURER:**PANEL TYPE:**

Chief Buildings	MVF/MVP
Chief Buildings	STC Panel
Classic Roofing Systems	CR-S 25
Classic Roofing Systems	CR-S 38
Coated Metals Group CMG	Ultra-Seam
Coated Metals Group CMG	Ultra-Snap
Coated Metals Group CMG	Ultra-Flange 1" and 1.5"
Construction Metals, Inc.	Barrier Roof
Construction Metals, Inc.	Sur-lock
Corle Building Systems	Seam-Lok
Corle Building Systems	Verticle-Lok
Corle Building Systems	Snap-Seal
Copper Sales	UC-3
Copper Sales	UC-4
Copper Sales	UC-6
Custom Bilt Metals	CB-150
Custom Bilt Metals	CB-100
Custom Bilt Metals	SL-100
Custom Bilt Metals	SLZ 1000/1500
Dean Steel Buildings, Inc.	Pro Seam and Pro Lok
Dimensional Metals, Inc.	Tee-Lock TL25
Dimensional Metals, Inc.	Span-Lock SL25 and SL20
Dimensional Metals, Inc.	Inter-Lock IL20
Dimensional Metals, Inc.	Double-Lock DL 15
Dimensional Metals, Inc.	Snap-On-Seam SS10 and SS15
Dimensional Metals, Inc.	Nail-Strop NS10 & NS15
Drexel Metals	100SS and 150SS
Drexel Metals	200S
Drexel Metals	100NS
Drexel Metals	150SL & 175S Snap Lock
Drexel Metals	450, 450SL, 550S
Drexel Metals	DMC 210S Armco Type
Englert	A1000, A1100
Englert	A1300, A1301, A1500
Englert	Everloc Nailstrip
Englert	EverSeam
Fab Tech, Inc.	Seam-Lok
Fab Tech, Inc.	Snap-Seal
Fabral	1-1/2" SSR
Fabral	Stand 'N Seam

MANUFACTURER:**PANEL TYPE:**

Fabral	Powerseam
Fabral	Thin Seam & Slim Seam
Follansbee Steel	1" (25mm) DF (TCS)
Firestone	Una-Clad, UC-3, UC-4, UC-6, UC-14
Galvak, S.A. De C.V.	Galvalok I
Galvak, S.A. De C.V.	Galvalok II
Garco Building Systems	BattenLok HS
Garco Building Systems	SuperLok
Garco Building Systems	LokSeam
Garco Building Systems	Ultra-Dek
Garco Building Systems	Double-Lok
Garland	R-Mer Loc
Garland	R-Mer Span
Imetco	Series 300 1" Batten
Imetco	PermLok
Imetco	TwinLok
Inland Buildings	TS-324
Inland Buildings	VS-216
Inland Buildings	SS20
Inland Buildings	IN-LOC
Interlock Roofing	Nailstrip
KalZip	50 Series
KalZip	65 Series
Kingspan	KingZip 1020
Kirby Building Systems	KLM 2100, KLS 2100
Kirby Building Systems	Roof-Lok/Roof-Lok Plus
Knudson Mfg	KR-18
Knudson Mfg	KR-20
Knudson Mfg	KR-24
Laura Star-Roof. BV	SpanLock
Laura Star-Roof. BV	Artlock
Lysaght	Longline 305
MBCI	BattenLok/BattenLok HS
MBCI	DoubleLok/LokSeam
MBCI	SuperLok/Ultradek
McElroy Metal	138T/238T
McElroy Metal	Instaloc
McElroy Metal	MasterLok-90/FS
McElroy Metal	Maxima
McElroy Metal	Medallion-Lok

MANUFACTURER:**PANEL TYPE:**

McElroy Metal	Meridian
Merchant & Evans	Zip Rib
Merchant & Evans	Zip-Lok
Merchant & Evans	#305
Merchant & Evans	#306
Mesco Building Solutions	Double-Lok/Ultra-Dek
Metal Sales	Magna-Loc, Magna-Loc 180, Curved Magna-Loc
Metal Sales	Vertical Seam
Metal Sales	Seam-Loc
Metal Sales	Snap-Loc
Metal Sales	Image II
Metal Sales	T-Armor
Met-Fab by Drexel	Historic
Met-Fab by Drexel	MetFab III
Met-Fab by Drexel	Snap-On 400
Met-Fab by Drexel	Snap-On 550 and Snap-On 675
Metl-Span	CFR
Morin by Kingspan	SLR
Morin by Kingspan	SRR
Morin by Kingspan	SWL
Mid-West by NCI	BattenLok/Double-Lok
Mid-West by NCI	SuperLok/Ultra-Dek
New Tech Machinery	SS100/SS150/SS200/SS210A/SS450(sl)
New Tech Machinery	SS450/SS450SL/SS550/SS675
New Tech Machinery	FF 100, 150
North Star Metals	Loc Star
North Star Metals	Snap Star
North Star Metals	NS-18
Nu-Ray Metals	NRM 1000/NRM 1750/NRM 2000
Nucor Building Systems	CFR/SR2/VR16 II
OC Metals	SMI 1.5
OC Metals	SMI Mechanical 450
Pac-Clad by Petersen Aluminum	Snap-Clad
Pac-Clad by Petersen Aluminum	Tite-Loc/Tite-Loc HS/Tite-Loc Plus
Pac-Clad by Petersen Aluminum	Snap-On Standing Seam
Pac-Clad by Petersen Aluminum	Hi Snap On
Pac-Clad by Petersen Aluminum	Redi-Roof/Edge-Loc
Patterson Aluminum Corp	Snap Clad
Premier Metals	Standing Seam 1.5
Rigid Global Buildings	Hi-Tech























MANUFACTURER:**PANEL TYPE:**

Rigid Global Buildings	Platinum
Robertson Building Systems	BattenLok, Curved BattenLok, DoubleLok
Robertson Building Systems	LokSeam, SuperLok, UltraKeck
Robertson Building Systems	Starshield-SSR
Schlebach	1 Inch Nail Strip Panel
Schlebach	1.5 Nail Strip
Schulte Building Systems	TS-324
Schulte Building Systems	VS-216
Star Building Systems	Starshield
Steel Span, Inc.	Trapazoidal
Steel Span, Inc.	Architectural
Steel Tile	Snap Seam 1.5"
Steel Tile	Nail Strip 1.5"
Steel Tile	Mechanical Lock 1.5"
Steelway Building Systems	RTL-24
Taylor Metals	Easy Lock
Taylor Metals	Versa-Span
Taylor Metals	MS 150 / MS 200
Taylor Metals	Clip Lock
Tremco	TremLock VP
Tremco	T-238
Tremco	TremLock SL and LSP
Triad Corrugated Metal	Snap Loc
Triad Corrugated Metal	Nailstrip
Triad Corrugated Metal	Mechanical
U.S. Metals	US-150
Ultra Seam, Inc.	Ultra Seam US-150C, 150CL, 150LS
Ultra Seam, Inc.	Ultra Seam US-100NS Nail Strip
Una-Clad	Una-Clad UC-3, UC-4, UC-6, UC-14
Union Corrugating Company	Advantage Lok & Advantage-Lok II
Union Corrugating Company	SL150
Union Corrugating Company	ML150
Union Corrugating Company	Guardian 1 / II / Lok
Union Corrugating Company	Sure-Lok / Supreme-Lok
Varco Pruden	SSR
Varco Pruden	HWR
Varco Pruden	SLR
Vic West	Prestige
Vic West	Tradition-100
Vic West	TSR

MANUFACTURER:**PANEL TYPE:**

Vic West	Tradition 150-4
Whirlwind Building Systems	Weather Lok-16
Whirlwind Building Systems	Weather Snap-16
Whirlwind Building Systems	Super Seam II/Super Seam Plus
Zamil Steel Industries	Max Seam
Zimmerman Metals, Inc.	SL-1500, SL1750, SLC1000
Zimmerman Metals, Inc.	SS1500, SS2000, SS2500, TSS2500

▶ 18.0 SAFEWAZE ANNUAL INSPECTION FORM

Inspection Date:	Inspector:	Pass/Fail:  	Comments/ Corrective Action:
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	

Address: 225 Wilshire Ave SW, Concord, NC 28025**Phone:** (800) 230-0319**Fax:** 704-262-9051**Email:** info@safewaze.com**Website:** safewaze.com



SAFEWAZE

024-4115 (acero) y 025-4126 (nailon)

**Manual sobre el anclaje para barra
de junta vertical**



NORMAS	
ANSI	N/A
OSHA	1926.502, 1910.140, 1910.66

* Este manual pretende cumplir con las instrucciones del fabricante especificadas por el Instituto Nacional Estadounidense de Estándares (American National Standards Institute, ANSI) y debe utilizarse en el programa de capacitación para empleados según lo requerido por la Administración de Seguridad y Salud Ocupacional (Occupational Safety and Health Administration, OSHA).*

**Asegúrese de leer y comprender las instrucciones antes de usar el equipo.
¡No descarte las instrucciones!**

Siempre compruebe que está utilizando la versión más reciente del manual de Safewaze. Visite el sitio web de Safewaze o comuníquese con el Servicio al Cliente para obtener los manuales actualizados.

⚠ IMPORTANTE:

- Consulte este manual para conocer las instrucciones fundamentales sobre el uso, el cuidado o la idoneidad del equipo para su aplicación. Comuníquese con Safewaze si tiene otras preguntas.
- Registre toda la información importante sobre el producto antes de usarlo. En el registro de inspecciones, es obligatorio documentar todas las inspecciones anuales de las personas competentes.

▶ INFORMACIÓN SOBRE EL USUARIO

Fecha de primer uso: _____

Número de serie: _____

Capacitador: _____

Usuario: _____

▶ INFORMACIÓN DE SEGURIDAD Y PRECAUCIONES

- Los usuarios de este equipo deben recibir las instrucciones del fabricante.
- El usuario debe leer, comprender y seguir toda la información de seguridad y de uso incluida en este manual.
- El usuario debe usar el producto y todo el equipo que se usa junto con el producto de manera segura y efectiva.
- Si no se respeta toda la información de seguridad y de uso, pueden provocarse lesiones graves o la muerte.

Advertencias:

Las normas incluidas en este documento no son exhaustivas, solo sirven de referencia y no pretenden reemplazar el criterio de una persona competente o su conocimiento de los estándares federales o estatales.

Las advertencias que se indican a continuación están diseñadas para minimizar los riesgos asociados al uso del anclaje para barra de junta vertical.

- Los usuarios deben consultarle a su médico si tienen la capacidad de absorber la fuerza de un evento de detención de caídas de manera segura. El estado físico, la edad y otros aspectos de la salud pueden afectar enormemente la capacidad de una persona de soportar las fuerzas de la detención de caídas. Las mujeres embarazadas y las personas que se consideren menores de edad no deben usar ningún equipo de Safewaze.
- No modifique el equipo ni lo use de manera incorrecta. Solo Safewaze, o las entidades a las que Safewaze autorizó por escrito, pueden hacer reparaciones al equipo de protección contra caídas de Safewaze.
- Una persona competente debe analizar el lugar de trabajo y anticipar dónde realizarán las tareas los trabajadores, el camino que tomarán para llegar al trabajo y cualquier peligro de caídas existente y posible. La persona competente debe elegir el equipo de protección contra caídas que se utilizará. La elección dependerá de las condiciones potencialmente peligrosas del lugar de trabajo. Todo el equipo de protección contra caídas debe adquirirse nuevo y sin usar.
- Si el trabajo se realizará en un entorno de altas temperaturas, se deberá utilizar un equipo de protección contra arcos eléctricos u otros equipos de protección contra caídas adecuados.
- No se permite utilizar cinturones para detener una caída.
- En la medida de lo posible, se debe trabajar directamente debajo del punto de anclaje para minimizar los peligros de caídas pendulares.
- Cuando trabaja en las alturas, el usuario debe asegurarse de que haya una altura de caída adecuada.
- Los anclajes que estén expuestos a fuerzas de detención de caídas deben retirarse inmediatamente del servicio y destruirse.
- Una persona competente debe capacitar a las personas autorizadas sobre las formas correctas de instalación, inspección, desmontaje, mantenimiento, almacenamiento y uso del equipo. Este entrenamiento debe incluir la capacidad de reconocer peligros de caídas, minimizar la posibilidad de que haya peligros de caídas y el uso correcto de los sistemas personales de detención de caídas.
- Si la capacitación se dicta con este equipo, debe instalarse y utilizarse un sistema de protección contra caídas secundario para garantizar que el aprendiz no esté expuesto a peligros de caídas accidentales.
- El equipo designado para la protección contra caídas nunca debe usarse para levantar, colgar, sostener o elevar herramientas u otros equipos a menos que tenga la certificación específica para ese uso.
- Evite utilizar el anclaje en aplicaciones en las que exista riesgo de quedar atrapado.
- Evite manipular maquinaria, bordes filosos o abrasivos, y cualquier otro elemento peligroso que podría dañar o deteriorar el componente.
- Preste especial atención para que la línea salvavidas esté libre de obstáculos, que pueden incluir, entre otros, objetos cercanos, herramientas, equipos, maquinaria en movimiento, compañeros de trabajo, usted mismo u objetos que podrían impactarlo desde arriba.
- Asegúrese de que el revestimiento del techo esté fijado a un elemento estructural capaz de soportar las cargas estáticas requeridas por este producto antes de realizar la instalación.
- Use únicamente los sujetadores aprobados por Safewaze para usar con este dispositivo.
- Siempre verifique que las abrazaderas de junta del dispositivo sean compatibles con la junta del techo.
- No instale el dispositivo sobre superficies inclinadas (p. ej., vigas en S).

ÍNDICE

1.0 ► Introducción	5
2.0 ► Uso previsto	5
3.0 ► Normas de seguridad aplicables	5
4.0 ► Clasificación de los trabajadores	5
5.0 ► Plan de rescate	6
6.0 ► Limitaciones del producto	6
7.0 ► Aplicaciones permitidas de anclaje	7
8.0 ► Especificaciones del producto	8
9.0 ► Altura de caída	8
10.0 ► Compatibilidad de los conectores	11
11.0 ► Formación de conexiones	11
12.0 ► Antes de la instalación del anclaje	12
13.0 ► Instalación del anclaje	13
14.0 ► Inspección	15
15.0 ► Mantenimiento	17
16.0 ► Etiquetas	17
17.0 ► Información sobre la junta vertical	18
18.0 ► Formulario de inspección anual	24

► 1.0 INTRODUCCIÓN

Gracias por haber adquirido un anclaje para barra de junta vertical. Este manual debe leerse y comprenderse en su totalidad y utilizarse como parte del programa de capacitación de empleados requerido por la OSHA o por cualquier agencia estatal aplicable.

Este anclaje reutilizable fácil de instalar está diseñado para instalarse en un techo de junta vertical plana o inclinada con un calibre mínimo de 26 o sobre placas de acero, vigas y perfiles angulares de hierro de ¼ in a 1 in (6 mm –25 mm) de espesor. El anclaje para barra de junta vertical funciona como un conector de anclaje simple para equipos de protección contra caídas y puede utilizarse con cordones con amortiguación de energía, Líneas Salvavidas Autorretráctiles (Self-Retracting Lifelines, SRL) y Líneas Salvavidas Verticales (Vertical Lifelines, VLL). El anclaje SOLO puede usarse para líneas salvavidas horizontales (Horizontal Lifeline, HLL) si se instala en placas de acero, vigas o perfiles angulares de hierro. El anclaje no puede usarse para líneas salvavidas horizontales ni juntas verticales. El anclaje no es adecuado para usar para transporte de materiales.

► 2.0 USO PREVISTO

El uso previsto del equipo detallado en este manual es formar parte de un sistema personal de protección contra caídas completo. Safewaze no aprueba el uso de este equipo para cualquier otro objetivo, que incluyen, entre otros, deportes o actividades recreativas, aplicaciones de manejo de materiales no aprobadas u otras acciones que no se describen en estas instrucciones.

Si se usa este equipo de un modo no especificado en este manual, podría provocar lesiones graves o la muerte. Solo el personal capacitado debe usar el equipo detallado en este manual para aplicaciones en su lugar de trabajo. Si el anclaje se utiliza para capacitación, se debe utilizar un sistema secundario de protección contra caídas para que el aprendiz no esté expuesto a riesgos de caídas accidentales.

► 3.0 NORMAS DE SEGURIDAD APLICABLES

Si se usa en cumplimiento de las instrucciones, este producto cumple con las normas **1926.502, 1910.66 y 1910.140 de la OSHA**. Los estándares y las normas aplicables dependerán del tipo de trabajo que se realice y podrían incluir normas específicas del estado.

Consulte los requisitos locales, estatales y federales para obtener más información sobre la legislación de la seguridad laboral respecto de los sistemas personales de detención de caídas (Personal Fall Arrest Systems, PFAS).

► 4.0 CLASIFICACIÓN DE LOS TRABAJADORES

Asegúrese de leer y comprender las definiciones de las personas que trabajan en lugares con riesgos de caídas o pueden estar expuestas a ellos:

Ingeniero calificado: una persona que posee un título universitario en ingeniería de una institución acreditada. Puede asumir responsabilidad individual para el desarrollo y la aplicación de la ingeniería y sus conocimientos en el diseño, la construcción, el uso y el mantenimiento de sus proyectos.

Persona calificada: alguien que, debido a que posee un título o certificado reconocido, historia profesional o vastos conocimientos, capacitaciones y experiencia, ha comprobado ser capaz de solucionar o resolver problemas relacionados con un tema específico, el trabajo o el proyecto.

Persona competente: alguien que es capaz de identificar peligros existentes y previsible a sus alrededores o condiciones laborales insalubres, riesgosas o peligrosas para los empleados, y que tiene la autorización para llevar a cabo medidas correctivas inmediatas para resolverlo.

Persona autorizada: una persona a quien el empleador aprobó o asignó para realizar un tipo específico de tareas o para estar en una ubicación específica en el lugar de trabajo.

La persona calificada o el ingeniero tienen la responsabilidad de supervisar el lugar de trabajo y garantizar que se cumplan las normas de seguridad.

► 5.0 PLAN DE RESCATE

Antes de utilizar este equipo, los empleadores deben crear un plan de rescate para eventos de caídas y proporcionar los medios para implementar el plan mediante capacitaciones. El plan de rescate debe ser específico de cada proyecto. Debe permitirles a los empleados que puedan rescatarse a sí mismos o que los puedan rescatar otros inmediatamente con medios alternativos.

Todos los usuarios del equipo, las personas autorizadas y los rescatistas deben conocer y comprender el plan. Se puede necesitar equipo especializado no incluido en el alcance de este manual para las operaciones de rescate. Todos los usuarios deben recibir capacitación sobre la inspección, la instalación, la operación y el uso adecuado de su equipo de rescate y del plan de rescate. Consulte la norma Z359.4-2013 del ANSI para obtener información específica sobre el rescate. Debe buscar atención médica inmediata si un trabajador se expone a un incidente de detención de caídas.

Nota: Pueden necesitarse medidas de rescate especiales para caídas de un borde.

► 6.0 LIMITACIONES DEL PRODUCTO

Consulte los siguientes requisitos y limitaciones cuando instale o utilice este equipo:

- **Rango de capacidad:** según el ANSI, 130-310 lb (59-141 kg) y, según la OSHA, hasta 420 lb (191 kg). * Incluye el peso de la ropa, las herramientas, el equipo, etc.
- **Anclaje:** los anclajes seleccionados para los sistemas de detención de caídas deben tener una fuerza capaz de soportar cargas estáticas aplicadas en las direcciones permitidas por el sistema de, al menos:
 1. 5,000 lb (2267.9 kg) para anclajes no certificados.
 2. El doble de la fuerza de frenado máxima para anclajes certificados.
 3. 3,100 lb para aplicaciones de rescate.

Si se conecta más de un sistema de detención de caídas a un anclaje, la fuerza que se indica arriba debe multiplicarse por la cantidad de sistemas conectados al anclaje.

Según las normas 1926.502 y 1910.66 de la OSHA: los anclajes que se utilicen para la conexión de sistemas personales de detención de caídas deben ser independientes de cualquier anclaje que se utilice para soportar o suspender plataformas y debe ser capaz de soportar, al menos, 5,000 lb (2267.9 kg) por usuario. De otro modo, los anclajes para la conexión deben diseñarse, instalarse y utilizarse como parte de un PFAS completo que mantenga un factor de seguridad de al menos dos y esté bajo la supervisión de una persona calificada.

- **Velocidad de bloqueo:** la naturaleza de este equipo requiere una trayectoria de caída despejada para garantizar que la SRL se bloquee en caso de caída. Si se trabaja en caminos de caída obstaculizados, zonas estrechas o con movimiento de materiales, como arena y granos, puede suceder que el cuerpo del usuario no alcance la velocidad necesaria para que la SRL se active y se bloquee durante la caída.
- **Caída libre:** el máximo de caída libre permitido es de 6 pies. Limite la distancia de caída libre al mantener el anclaje en línea con el área de trabajo.
- **Caídas pendulares:** si el usuario se mueve lateralmente alejándose del punto de anclaje sobre la cabeza, aumenta el riesgo de que se produzca una caída pendular. La fuerza producida por golpear un objeto en una caída pendular, en algunos casos, genera más fuerzas que una caída sin que el usuario utilice equipo de protección. Dentro de lo posible, se debe trabajar directamente debajo del punto de anclaje para minimizar el riesgo de caídas pendulares.
- **Altura de caída:** la altura de caída (Fall Clearance, FC) es el valor total de la combinación de elongación de la cuerda, longitud del cordón, distancia de desaceleración, estiramiento del arnés, altura del trabajador y un factor de seguridad. Safewaze usa un factor de seguridad de 2 ft. Este factor de seguridad incluye el deslizamiento del dispositivo de detención de caída. Consulte el manual del producto del sistema PFAS al calcular la altura de caída.

Se requiere una altura de caída adicional para caídas desde una posición arrodillada o en cuclillas. Si existe un riesgo de caída pendular, la distancia vertical total de la caída será mayor que si la persona hubiera caído directamente debajo del punto de anclaje. Este manual ofrece información sobre los riesgos de caídas pendulares y requisitos adicionales de altura de caída en la Sección 9.

- **Peligros:** si este equipo se usa en un entorno donde existen peligros, se deben tener precauciones adicionales. Los peligros pueden incluir, entre otros, maquinaria en movimiento, equipos de alta tensión o líneas eléctricas, sustancias químicas irritantes, entornos corrosivos, gases tóxicos o explosivos, o calor extremo. Se debe evitar trabajar en zonas donde el equipo o el personal que se encuentra por encima de la cabeza pueden caerse y golpear contra el usuario, el equipo de protección contra caídas o la línea salvavidas. Se deben evitar las zonas en las que la línea salvavidas del usuario puede cruzarse o enredarse con la de otro usuario. La línea salvavidas no debe pasar por debajo de los brazos o entre las piernas.
- **Bordes afilados:** las SRL Clase 2 de Safewaze están diseñadas para su uso sobre la cabeza y en entornos con bordes abiertos. Si un área de trabajo específica tiene uno o varios bordes extremadamente afilados que pueden entrar en contacto con la línea salvavidas de la SRL, se requiere una SRL de Clase 2.

► 7.0 APLICACIONES PERMITIDAS DE ANCLAJE

Detención de caídas personales: los anclajes de Safewaze están diseñados como un punto de anclaje para soportar un máximo de un PFAS cuando se utilicen en aplicaciones de protección contra caídas. La estructura a la que se fija el anclaje debe resistir cargas aplicadas en las direcciones permitidas por el sistema de, al menos, 5,000 lb (22 kN) o estar diseñada con un factor de seguridad de dos a uno. La caída libre máxima permitida depende del conector utilizado.



Restricción: los anclajes de Safewaze están autorizados para uso en aplicaciones de restricción. La estructura a la que se fija el anclaje debe resistir cargas aplicadas en las direcciones permitidas por el sistema de, al menos, 1,000 lb. NO se permite caída libre. Los sistemas de restricción solo pueden utilizarse en superficies con una pendiente máxima de 4/12 (vertical/horizontal). Para aplicaciones de restricción, los puntos de conexión permitidos al arnés son los anillos en D dorsal, frontal/externa, lateral y de hombro.



Posicionamiento de trabajo: los anclajes de Safewaze están autorizados para uso en aplicaciones de posicionamiento de trabajo. El posicionamiento de trabajo permite que el trabajador esté sostenido durante la suspensión, dejando ambas manos libres para realizar operaciones. La estructura a la que se fija el anclaje debe resistir cargas aplicadas en las direcciones permitidas por el sistema de, al menos, 3,000 lb. La caída libre máxima permitida es de 2 ft. En aplicaciones de posicionamiento, los puntos de conexión permitidos al arnés son los anillos en D laterales.



Rescate/espacios confinados: los anclajes de Safewaze están autorizados para uso en aplicaciones de rescate o espacios confinados. Los sistemas de rescate se utilizan para recuperar de forma segura a un trabajador desde un lugar confinado o después de una caída. La composición de los sistemas de rescate puede variar según el tipo de rescate involucrado. La estructura a la que se fija el anclaje debe resistir cargas aplicadas en las direcciones permitidas por el sistema de, al menos, 3,100 lb. NO se permite caída libre en situaciones de rescate. En situaciones de espacios confinados, la caída libre máxima permitida depende del PFAS utilizado. En estas aplicaciones, los puntos de conexión permitidos al arnés son los anillos en D dorsal, frontal/esternal y de hombro.



► 8.0 ESPECIFICACIONES DEL PRODUCTO

- Capacidad: 1 usuario, según el ANSI, 130-310 lb (59-141 kg) y, según la OSHA, hasta 420 lb (191 kg). * Incluye el peso de la ropa, las herramientas, el equipo, etc.
- Conector de anclaje de punto único, temporal, reutilizable y no penetrante, con anillo en D giratorio de 360°.
- Materiales: anclaje (aluminio), anillo en D (acero inoxidable), cubierta de etiqueta (poliéster)
- Resistencia mínima a la rotura (MBS):
 - » Juntas verticales: 5,000 lb (22 kN) cuando se usa en paralelo con la junta o 3,600 lb (16 kN) para usarlo a 360°.
 - » Placas de acero, vigas y perfiles angulares de hierro: 5,000 lb (22kN) en todas las direcciones.
- Peso del artículo: 3 lb (1.4 kg)
- Ubicación de instalación:
 - » Calibre del techo de junta vertical: se requiere un calibre mínimo de 26 para la instalación del anclaje.
 - » Especificaciones para placas de acero, vigas y perfiles angulares de hierro: debe ser de ¼ in-1 in (6 mm - 25 mm) de espesor.
- Incluye: (12) tornillos de fijación de acero inoxidable con 024-4115 o 12 tornillos de fijación de acero inoxidable con puntas de nailon con 025-4126
- Productos relacionados:
 - » (12) tornillos de fijación con punta de nailon para junta vertical (025-4127)
 - » (12) tornillos de fijación de acero inoxidable para junta vertical (025-4128)

► 9.0 ALTURA DE CAÍDA


Siempre seleccione una SRL/un cordón y un punto de anclaje que limiten al máximo la caída libre y la caída pendular. Consulte los manuales del sistema PFAS elegido para obtener información sobre la altura de caída. Una caída libre de más de 6 pies puede generar fuerzas de detención excesivas que podrían causar lesiones graves o la muerte.

- **Altura de caída:** debe haber suficiente distancia debajo del conector de anclaje para detener una caída antes de que el usuario golpee el suelo o un obstáculo. Al calcular la altura de caída, se deben considerar todos los factores aplicables. Una persona competente debe evaluar los componentes de todo el sistema para calcular la altura de caída.


LOS SIGUIENTES DIAGRAMAS SON SOLO EJEMPLOS.

Nota: Los números utilizados en estos ejemplos se basan en un desplazamiento y retroceso CERO con el anclaje directamente encima o debajo, para representar un cálculo de altura de caída en línea. Consulte con una persona competente cuando trabaje en escenarios diferentes y cuando utilice equipos que no sean de Safewaze.

EJEMPLO DE CORDÓN DE CAÍDA LIBRE DE 6 FT (POR ENCIMA DE LA CABEZA)



EJEMPLO DE CORDÓN DE CAÍDA LIBRE DE 12 FT (POR DEBAJO DEL ANILLO EN D)



EJEMPLO CLASE 1 (POR ENCIMA DE LA CABEZA)


ALTURA NECESARIA DESDE EL ANCLAJE 13 FT		ALTURA DEL ANCLAJE DE 6 FT	
ALTURA NECESARIA DESDE LA SUPERFICIE DE TRABAJO 7 FT		CAÍDA LIBRE DE 0 FT	SUPERFICIE DE TRABAJO
DISTANCIA DE DETENCIÓN MÁX. 42 IN SEGÚN Z359.14-2021 DEL ANSI CLASE 1		3.5 FT	
ESTIRAMIENTO DEL ARNÉS MÁX. 18 IN SEGÚN Z359.11-2021 DEL ANSI		1.5 FT	
		FACTOR DE SEGURIDAD	2 FT
		DISTANCIA DE CAÍDA PENDULAR	A DEFINIR

EJEMPLO CLASE 2 (POR DEBAJO DEL ANILLO EN D)

	ALTURA DEL ANCLAJE DE 0 FT		CAÍDA LIBRE DE 5 FT
	SUPERFICIE DE TRABAJO		
	DISTANCIA DE DETENCIÓN CONSULTE EL MANUAL PARA CONOCER LAS DISTANCIAS DE CAÍDA PUBLICADAS SEGÚN LA NORMA Z359.14-2021 DEL ANSI CLASE 2	8 FT	ALTURA NECESARIA DESDE LA SUPERFICIE DE TRABAJO 16.5 FT
	ESTIRAMIENTO DEL ARNÉS MÁX. 18 IN SEGÚN Z359.11-2021 DEL ANSI	1.5 FT	
	ALTURA DEL TRABAJADOR SUPERFICIE DE TRABAJO AL ANILLO EN D DORSAL	5 FT	
	FACTOR DE SEGURIDAD	2 FT	
	DISTANCIA DE CAÍDA PENDULAR	A DEFINIR	

- Caidas pendulares:** antes de la instalación o el uso, se deben tomar medidas para eliminar o minimizar todos los riesgos de caídas pendulares. Las caídas pendulares ocurren cuando el anclaje no está directamente sobre el lugar donde ocurre la caída. Siempre trabaje lo más cerca posible o en línea con el punto de anclaje. Las caídas pendulares aumentan significativamente la probabilidad de sufrir lesiones graves o la muerte en caso de una caída. Asegúrese de que una persona competente incluya los cálculos de una caída pendular si existe el peligro.


CAÍDA PENDULAR:



► 10.0 COMPATIBILIDAD DE LOS CONECTORES

- El equipo de Safewaze está diseñado y probado con los componentes o sistemas asociados de Safewaze. Si se realizan sustituciones o reemplazos, asegúrese de que todos los componentes cumplan con los requisitos aplicables del ANSI. Lea y siga las instrucciones del fabricante para todos los componentes y subsistemas de su PFAS. Si no se siguen estas indicaciones, se puede poner en riesgo la compatibilidad del equipo y afectar la seguridad y la fiabilidad del sistema.
- Los conectores son compatibles con los elementos de conexión cuando están diseñados para trabajar juntos de modo que sus tamaños y formas no provoquen la apertura accidental de los mecanismos de cierre, sin importar su orientación.
- Los conectores (ganchos, mosquetones y anillos en D) deben poder soportar, al menos, 5,000 lb (22 kN).
- Los conectores deben ser compatibles con el anclaje u otros componentes del sistema.
- No utilice equipo que no sea compatible. Los conectores no compatibles pueden soltarse accidentalmente.
- Los conectores deben ser compatibles en tamaño, forma y resistencia.
- Los ganchos de cierre automático y los mosquetones son obligatorios según las normas de la OSHA.
- Algunos conectores especiales tienen requisitos adicionales. Comuníquese con Safewaze si tiene alguna pregunta sobre la compatibilidad.

DESENGANCHE ACCIDENTAL:



Si se usa un conector que sea demasiado pequeño o tenga una forma irregular (1) para conectar un gancho de cierre o un mosquetón, puede ocurrir que el conector fuerce la apertura del cierre del gancho o del mosquetón. Cuando se aplica fuerza, el cierre del gancho o del mosquetón presiona contra la parte no compatible (2) y fuerza la apertura del cierre (3). Esto permite que el gancho de cierre o el mosquetón se suelte (4) del punto de conexión.


► 11.0 FORMACIÓN DE CONEXIONES

Los ganchos de cierre y los mosquetones utilizados con este equipo deben ser de doble cierre y/o de cierre giratorio. Asegúrese de que todas las conexiones sean compatibles en tamaño, forma y resistencia. No utilice equipo que no sea compatible. Verifique que todos los conectores estén completamente cerrados y bloqueados.

Los conectores de Safewaze (ganchos, mosquetones y anillos en D) están diseñados para usarse únicamente según las especificaciones del manual de cada producto. Consulte la figura a continuación para ver ejemplos de conexiones inapropiadas. No conecte ganchos de cierre ni mosquetones:

- a un anillo en D al que ya esté unido otro conector.
- de manera que se genere una carga sobre el cierre (excepto en ganchos de sujeción de retorno).
- en una conexión falsa, donde partes salientes del gancho de cierre o del mosquetón se enganchen al anclaje y, sin confirmación visual, parezca que están completamente sujetos al punto de anclaje.
- entre sí.
- enrollando la línea salvavidas de correa tejida alrededor de un anclaje y asegurándola a la misma línea salvavidas, excepto en los modelos con sujeción de retorno.
- a cualquier objeto cuya forma o tamaño impidan que el gancho de cierre o el mosquetón se cierre y bloquee correctamente, o que pueda provocar liberación accidental.
- de manera que no permita que el conector se alinee correctamente cuando está cargado.


CONEXIONES INAPROPIADAS:



Los ganchos de cierre de boca ancha no deben conectarse a anillos en D de tamaño estándar ni a objetos similares que generen carga sobre el cierre si el gancho o el anillo en D se tuercen o giran, a menos que el gancho de cierre cumpla con la norma Z359.1-2007 o Z359.12 del ANSI e incluya un cierre de 3,600 lb (16 kN).


12.0 ► ANTES DE LA INSTALACIÓN DEL ANCLAJE

Antes de instalar el anclaje, una persona competente debe determinar que el lugar de instalación sea capaz de soportar las cargas previstas en el anclaje. Asegúrese de que el perfil de la junta sea compatible con el anclaje. El anclaje debe quedar asentado al ras sobre el panel de junta vertical. Los techos deben tener un espesor mínimo de panel de calibre 26 o de mayor espesor. Las placas de acero, vigas y perfiles angulares de hierro deben tener entre ¼ in - 1 in (6 mm - 25 mm) de espesor. El anclaje solo debe instalarse en superficies planas de acero. No se permiten superficies inclinadas (p. ej., vigas en S).



El área de trabajo debe estar libre de escombros y de cualquier material o equipo que pueda interferir con el funcionamiento adecuado del producto. Inspeccione la ubicación de instalación prevista para detectar peligros que incluyan, entre otros, corrosión, grietas, manchas de óxido, orificios, deterioro, desgaste o riesgos eléctricos. Además, use la Figura 1 para asegurarse de que el anclaje sea compatible con el perfil de la junta vertical antes de la instalación.

FIGURA 1: DIMENSIONES DE COMPATIBILIDAD DEL PERFIL DE JUNTA VERTICAL



Consulte las Páginas 18 a 24 para obtener una lista no exhaustiva de los paneles de junta vertical por marca y modelo. Siempre asegúrese de que las especificaciones y dimensiones del panel de junta vertical se encuentren dentro de las dimensiones permitidas (arriba) del anclaje antes de la instalación.

► 13.0 INSTALACIÓN DEL ANCLAJE PARA BARRA DE JUNTA VERTICAL

Instalación:

1. Determine si la estructura de junta vertical es compatible con el anclaje para barra de junta vertical.
2. Para la instalación, solo se deben usar tornillos de acero o con punta de nailon. Elija el tipo de tornillos de fijación al momento de la compra (024-4115 para acero o 025-4126 para nailon). Los números de pieza de los tornillos de reemplazo son 025-4127 (punta de nailon) o 025-4128 (acero).
3. Centre el anclaje en la junta del techo. Asegúrese de que la base del anclaje esté nivelada a la ubicación de instalación.
4. Instale todos los tornillos de fijación en el orden que se muestra (Figura 2). Ajústelos según el valor especificado de cada tipo de tornillo:
 - Valor de ajuste de los de acero = 90 in-lb
 - Valor de ajuste de los de punta de nailon = 180 in-lb
5. Repita la secuencia de ajuste (dos veces en total).
6. Una vez que se instale correctamente*, el usuario puede conectar un PFAS completo y compatible al punto de conexión de anillo en D del anclaje.

*Nota: Repita el proceso de ajuste antes de cada uso.

FIGURA 2: SECUENCIA DE INSTALACIÓN DE LOS TORNILLOS DE FIJACIÓN






FIGURA 3: RESISTENCIA MÍNIMA A LA ROTURA E INDICACIONES DE USO

Juntas verticales:

Placas de acero, vigas y perfiles angulares de hierro:



► 14.0 INSPECCIÓN

El usuario debe contar con las instrucciones en todo momento para su referencia y registrar la fecha del primer uso en la página 2.

El usuario debe retirar inmediatamente el sistema del servicio si se detectan defectos o daños, o si se expone a fuerzas de detención de caídas.

Área de trabajo:

- Se debe inspeccionar el área de trabajo para garantizar que la ubicación no tenga daños, como, entre otros, escombros, grietas, podredumbre, desmoronamiento, deterioro estructural, óxido y cualquier material peligroso.
- Una persona competente debe determinar si la ubicación donde se realizará la instalación soportará las cargas previstas.

Frecuencia:

- Una persona competente, que no sea el usuario, debe inspeccionar la el anclaje de la barra de junta vertical al menos una vez al año.
- Durante la inspección, la persona competente debe tener en cuenta todas las aplicaciones y los peligros a los que pudo haber estado expuesto el equipo durante el uso.
- La persona competente debe registrar las inspecciones en el Registro de inspecciones que se incluye en este manual (página 24) o en las etiquetas de la tabla de inspección de cada producto individual. La persona competente debe anotar sus iniciales en el lugar correspondiente junto con el mes y el año en el que se realizó la inspección. Todas las etiquetas individuales del equipo deben tener las mismas iniciales.


FRECUENCIA DE LA INSPECCIÓN:

Tipo de uso	Ejemplos de aplicación	Condiciones de uso	Frecuencia de la inspección por parte de la persona competente
Poco frecuente a leve	Rescates y espacios confinados, mantenimiento en fábricas	Buenas condiciones de almacenamiento, uso en interiores o uso poco frecuente en exteriores, temperatura ambiente, entornos limpios	Anual
Moderado a frecuente	Transporte, construcciones residenciales, servicios, almacenes	Condiciones de almacenamiento razonables, uso en interiores y uso intenso en exteriores, todas las temperaturas, entornos limpios o polvorientos	Semestral a anual
Intensa a continua	Construcciones comerciales, petróleo y gas, minería	Condiciones de almacenamiento adversas, uso prolongado o continuo en exteriores, todas las temperaturas, entornos sucios	Trimestral a semestral

Indicaciones:

- Antes de cada uso, inspeccione el anclaje en busca de posibles defectos, que incluyen, entre otros, partes faltantes, corrosión, deformación, picaduras, rebabas, superficies ásperas, bordes filosos, grietas, óxido, acumulaciones de pintura, calor excesivo, alteraciones y etiquetas faltantes o ilegibles. Inspeccione todos los componentes del dispositivo, como la base, las abrazaderas, los pernos y los tornillos de fijación.
- Antes de cada uso, el usuario debe inspeccionar y verificar que cada componente individual (Figura 4) del anclaje esté en condiciones seguras para su uso:
 1. Inspeccione el anclaje para verificar que no esté doblado ni desgastado.
 2. Asegúrese de que los tornillos de fijación estén presentes.
 3. Vuelva a ajustar los tornillos de fijación.

FIGURA 4: COMPONENTES DEL ANCLAJE



Anillo en D	1
Anclaje	2
Tornillos de fijación	3
Etiquetas	4

▶ 15.0 MANTENIMIENTO

Reparaciones:

Solo Safewaze, o las entidades a las que Safewaze autorizó por escrito, pueden hacer reparaciones al equipo de protección contra caídas de Safewaze.

Limpeza:

El anclaje puede limpiarse con agua y jabón neutro. El usuario debe eliminar toda la suciedad, posibles sustancias corrosivas y contaminantes del sistema antes y después de cada uso. Nunca utilice ningún tipo de sustancia corrosiva para limpiar el sistema.

El exceso de agua debe eliminarse con aire comprimido. Los herrajes pueden secarse con un paño limpio y seco. No guarde el sistema húmedo o mojado. Permita que el equipo se seque completamente antes de guardarlo.

Almacenamiento:

Antes de la instalación, guarde el anclaje en un lugar fresco y seco donde no esté expuesto a luz intensa, calor extremo, humedad excesiva o materiales o productos químicos posiblemente corrosivos.


Vida útil:

La vida útil del anclaje depende de las condiciones de trabajo, el cuidado y las inspecciones realizadas. Siempre que el sistema y todos sus componentes pasen la inspección, puede permanecer en servicio.

Eliminación:

Deseche el anclaje si la inspección revela una condición insegura o defectuosa. Si el sistema está dañado o no es apto para su uso, debe destruirse para evitar una reutilización accidental.

▶ 16.0 ETIQUETAS



225 Whitire Ave SW
Concord, NC 28025
USA
(800) 250-0319
safewaze.com

Número de serie:
XXXXXXXXXX

ANCLAJE PARA BARRA DE JUNTA VERTICAL

Materiales: aluminio, acero inoxidable

Normas: 1926.502, 1910.140 y 1910.95 de la OSHA

Capacidad: según el ANSI, 130-310 lb (59-141 kg), según la OSHA hasta 420 lb (191 kg)

CONSULTE EL MANUAL DEL PRODUCTO PARA CONOCER LAS ADVERTENCIAS ADICIONALES, LOS METODOS DE CONEXIÓN E INSTALACIÓN Y LOS PROCEDIMIENTOS DE INSPECCIÓN COMPLETOS.

⚠ ADVERTENCIA: Este equipo está diseñado para usarse como anclaje de protección de caídas. No lo use para transporte de materiales. Consulte el manual para conocer los usos aprobados en HLL. Los usuarios deben leer y seguir las instrucciones recibidas con este producto en la entrega. De lo contrario, se podrían producir lesiones graves o la muerte. Evite contacto con peligos, incluidos, entre otros, calor, sustancias químicas, electricidad, y bordes y superficies abrasivos o allados.

470-00422

INSPECCIÓN:

Inspeccione el anclaje según las instrucciones del fabricante antes de cada uso. Una persona competente debe inspeccionar el anclaje al menos una vez al año. Si el equipo no pasa la inspección o se expone a fuerzas de detención de caídas, DEBE RETIRARSE DE SERVICIO DE INMEDIATO.

INSTALACIÓN:

- Elija el tipo de tornillo de fijación (solo con punta de nailón o tornillos de acero).
- Determine si la estructura de junta vertical es compatible con el anclaje.
- Centre el anclaje sobre la junta del techo y asegúrese de que la base quede asentada al ras en el lugar de instalación.
- Instale todos los tornillos de fijación y ajustelos según el valor especificado de cada tipo de tornillo:
 - Valor de ajuste de los de acero = 90 in-lb
 - Valor de ajuste de los de punta de nailón = 100 in-lb
- Repita la secuencia de ajuste dos veces.
- Una vez instalado correctamente, conecte el PFAS al punto de conexión del anillo en D del anclaje.

REGISTRO DE INSPECCIÓN

FECHA	INICIAL								

470-00422

RESISTENCIA MÍNIMA A LA ROTURA (MBS):

- 5,000 lb (22 kN) cuando se usa en paralelo con la junta.
- 3,600 lb (16 kN) para uso a 360°

REQUISITOS DE LA ESTRUCTURA:

Los techos deben tener un espesor mínimo de panel de calibre 26 o de mayor espesor. Las placas de acero, vigas y perfiles angulares de hierro deben tener entre 1/4 in (6 mm) y 1 in (25 mm) de espesor. **ADVERTENCIA:** Instale solo en superficies planas de acero. No se permiten superficies onduladas (p. ej., vigas en S).



470-00424

► 17.0 INFORMACIÓN SOBRE LA JUNTA VERTICAL

Aviso legal: esta es una lista no exhaustiva solo para referencia sobre los paneles de junta vertical por marca y modelo. Safewaze no tiene control sobre la fabricación, las tolerancias, las especificaciones y las variaciones de estos paneles mencionados. Siempre verifique que las especificaciones y dimensiones del panel de junta vertical se encuentren dentro de las dimensiones permitidas (Figura 1) del anclaje antes de la instalación.

FABRICANTE:	TIPO DE PANEL:
A&S	BattenLok HS
A&S	SuperLok
A&S	DoubleLok
A&S	Ultra-Dek
A&S	CFR 30", 36", 42"
A&S	DuraSeal Seam/DuraSeal Snap
AB Martin Roofing	ABSeam 19.5
AB Martin Roofing	ABM 1" Nail Strip
ACI Metal Roofing	SnapLok
ACI Metal Roofing	Stratoshield
ACI Metal Roofing	UltraLok
AEP Span	Design Span hp
AEP Span	Span Lok
AEP Span	SpanSeam
AEP Span	Multilok
AEP Span	Skyline / Skyline hp
AEP Span	Snap Seam
AEP Span	Sterling Roof System
AEP Span	High Seam
Agway Metals	AR Standing Seam, NS, SL
Alcan	Snap Lock 1" and 1.5"
Alcan	Mechanical Lock 1" & 1.5"
All Weather Insulated Panels	SR Series (Single Fold)
American Buildings de Nucor	Seam-Loc
American Buildings de Nucor	Loc/Seam/Loc Seam 360
American Buildings de Nucor	Standing Seam II
American Buildings de Nucor	Standing Seam 360
American Construction Metals ACM	Kenloc, Stayloc, Mechloc
AMS-Arch. Metal Solutions	ArmorLock/SnapLock/ProLock
Architectural Building Components/McElroy	138T, 238T
Architectural Building Components/McElroy	Permaseam Interlock
Architectural Building Components/McElroy	Maxima ADV
AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc
AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc HS

FABRICANTE:**TIPO DE PANEL:**

AMSI-Architectural Metal Specialties, Inc	Peterson Tite-Loc Plus
ASP-Arch. Sheetmetal Prod.	Series SL/ML/MLC
ATAS	Dutch Seam
ATAS	Field-Lok FLL 1", 1.5"
Bax Steel	Bax-Lock
BC Steel Buildings	BCL-24-SD
BC Steel Buildings	BCL-24-MS
Behlen Building Systems	Roll-Lock/Triple-Lock/Quadri-Lock
Behlen Building Systems	ZL-24/Triple-Lock/Quadri-Lock
Bemo	Bemo Roof
Berridge	High Seam Tee-Panel
Berridge	Cee-Lock
Berridge	Zee-Lock
BHP	Zip Rib
Bridger Steel	Tru-Snap 1", 1.5"
Bridger Steel	Nail Strip 1" and 1.5"
Bryer Company	TBC-Ultra
Bryer Company	TBC-Superseam
Bryer Company	TBC-SuperCurve
Butler	MR-24
Butler	Genesis 360
Butler	CMR-24
Butler	VSR II
Carlisle Syntec	CM 175SL/CM 150SL Snap Lock
Carlisle Syntec	CM 200S/CM 150 SS
CBC Steel Buildings by Nucor	MS-24
CBC Steel Buildings by Nucor	SS-24
Ceco Buildings	Double-Lok
Ceco Buildings	BattenLok HS
Ceco Buildings	SuperLok
Ceco Buildings	CRP / CLP / CXP
Central States Manufacturing	Central Snap
Central States Manufacturing	Central Span
Central States Manufacturing	Central Seam Plus
Central States Manufacturing	Central Loc
Central Texas Metal Roofing Supply	ShurLoc 150
Central Texas Metal Roofing Supply	SpanLoc 100, 150
Centria	SRS-2 / SRS-3
Centria	SDP Series
Chief Buildings	MSC Panel

FABRICANTE:**TIPO DE PANEL:**

Chief Buildings	MVF/MVP
Chief Buildings	STC Panel
Classic Roofing Systems	CR-S 25
Classic Roofing Systems	CR-S 38
Coated Metals Group CMG	Ultra-Seam
Coated Metals Group CMG	Ultra-Snap
Coated Metals Group CMG	Ultra-Flange 1" and 1.5"
Construction Metals, Inc.	Barrier Roof
Construction Metals, Inc.	Sur-lock
Corle Building Systems	Seam-Lok
Corle Building Systems	Verticle-Lok
Corle Building Systems	Snap-Seal
Copper Sales	UC-3
Copper Sales	UC-4
Copper Sales	UC-6
Custom Bilt Metals	CB-150
Custom Bilt Metals	CB-100
Custom Bilt Metals	SL-100
Custom Bilt Metals	SLZ 1000/1500
Dean Steel Buildings, Inc.	Pro Seam and Pro Lok
Dimensional Metals, Inc.	Tee-Lock TL25
Dimensional Metals, Inc.	Span-Lock SL25 and SL20
Dimensional Metals, Inc.	Inter-Lock IL20
Dimensional Metals, Inc.	Double-Lock DL 15
Dimensional Metals, Inc.	Snap-On-Seam SS10 and SS15
Dimensional Metals, Inc.	Nail-Strop NS10 & NS15
Drexel Metals	100SS y 150SS
Drexel Metals	200S
Drexel Metals	100NS
Drexel Metals	150SL & 175S Snap Lock
Drexel Metals	450, 450SL, 550S
Drexel Metals	DMC 210S Armco Type
Englert	A1000, A1100
Englert	A1300, A1301, A1500
Englert	Everloc Nailstrip
Englert	EverSeam
Fab Tech, Inc.	Seam-Lok
Fab Tech, Inc.	Snap-Seal
Fabral	1-1/2" SSR
Fabral	Stand 'N Seam

FABRICANTE:**TIPO DE PANEL:**

Fabral	Powerseam
Fabral	Thin Seam & Slim Seam
Follansbee Steel	1" (25mm) DF (TCS)
Firestone	Una-Clad, UC-3, UC-4, UC-6, UC-14
Galvak, S.A. De C.V.	Galvalok I
Galvak, S.A. De C.V.	Galvalok II
Garco Building Systems	BattenLok HS
Garco Building Systems	SuperLok
Garco Building Systems	LokSeam
Garco Building Systems	Ultra-Dek
Garco Building Systems	Double-Lok
Garland	R-Mer Loc
Garland	R-Mer Span
Imetco	Series 300 1" Batten
Imetco	PermLok
Imetco	TwinLok
Inland Buildings	TS-324
Inland Buildings	VS-216
Inland Buildings	SS20
Inland Buildings	IN-LOC
Interlock Roofing	Nailstrip
KalZip	50 Series
KalZip	65 Series
Kingspan	KingZip 1020
Kirby Building Systems	KLM 2100, KLS 2100
Kirby Building Systems	Roof-Lok/Roof-Lok Plus
Knudson Mfg	KR-18
Knudson Mfg	KR-20
Knudson Mfg	KR-24
Laura Star-Roof. BV	SpanLock
Laura Star-Roof. BV	Artlock
Lysaght	Longline 305
MBCI	BattenLok/BattenLok HS
MBCI	DoubleLok/LokSeam
MBCI	SuperLok/Ultradek
McElroy Metal	138T/238T
McElroy Metal	Instaloc
McElroy Metal	MasterLok-90/FS
McElroy Metal	Maxima
McElroy Metal	Medallion-Lok

FABRICANTE:	TIPO DE PANEL:
McElroy Metal	Meridian
Merchant & Evans	Zip Rib
Merchant & Evans	Zip-Lok
Merchant & Evans	#305
Merchant & Evans	#306
Mesco Building Solutions	Double-Lok/Ultra-Dek
Metal Sales	Magna-Loc, Magna-Loc 180, Curved Magna-Loc
Metal Sales	Vertical Seam
Metal Sales	Seam-Loc
Metal Sales	Snap-Loc
Metal Sales	Image II
Metal Sales	T-Armor
Met-Fab by Drexel	Historic
Met-Fab by Drexel	MetFab III
Met-Fab by Drexel	Snap-On 400
Met-Fab by Drexel	Snap-On 550 and Snap-On 675
Metl-Span	CFR
Morin by Kingspan	SLR
Morin by Kingspan	SRR
Morin by Kingspan	SWL
Mid-West by NCI	BattenLok/Double-Lok
Mid-West by NCI	SuperLok/Ultra-Dek
New Tech Machinery	SS100/SS150/SS200/SS210A/SS450(sl)
New Tech Machinery	SS450/SS450SL/SS550/SS675
New Tech Machinery	FF 100, 150
North Star Metals	Loc Star
North Star Metals	Snap Star
North Star Metals	NS-18
Nu-Ray Metals	NRM 1000/NRM 1750/NRM 2000
Nucor Building Systems	CFR/SR2/VR16 II
OC Metals	SMI 1.5
OC Metals	SMI Mechanical 450
Pac-Clad by Petersen Aluminum	Snap-Clad
Pac-Clad by Petersen Aluminum	Tite-Loc/Tite-Loc HS/Tite-Loc Plus
Pac-Clad by Petersen Aluminum	Snap-On Standing Seam
Pac-Clad by Petersen Aluminum	Hi Snap On
Pac-Clad by Petersen Aluminum	Redi-Roof/Edge-Loc
Patterson Aluminum Corp	Snap Clad
Premier Metals	Standing Seam 1.5
Rigid Global Buildings	Hi-Tech



























FABRICANTE:**TIPO DE PANEL:**

Rigid Global Buildings	Platinum
Robertson Building Systems	BattenLok, Curved BattenLok, DoubleLok
Robertson Building Systems	LokSeam, SuperLok, UltraKeck
Robertson Building Systems	Starshield-SSR
Schlebach	1 Inch Nail Strip Panel
Schlebach	1.5 Nail Strip
Schulte Building Systems	TS-324
Schulte Building Systems	VS-216
Star Building Systems	Starshield
Steel Span, Inc.	Trapazoidal
Steel Span, Inc.	Architectural
Steel Tile	Snap Seam 1.5"
Steel Tile	Nail Strip 1.5"
Steel Tile	Mechanical Lock 1.5"
Steelway Building Systems	RTL-24
Taylor Metals	Easy Lock
Taylor Metals	Versa-Span
Taylor Metals	MS 150 / MS 200
Taylor Metals	Clip Lock
Tremco	TremLock VP
Tremco	T-238
Tremco	TremLock SL and LSP
Triad Corrugated Metal	Snap Loc
Triad Corrugated Metal	Nailstrip
Triad Corrugated Metal	Mechanical
U.S. Metals	US-150
Ultra Seam, Inc.	Ultra Seam US-150C, 150CL, 150LS
Ultra Seam, Inc.	Ultra Seam US-100NS Nail Strip
Una-Clad	Una-Clad UC-3, UC-4, UC-6, UC-14
Union Corrugating Company	Advantage Lok & Advantage-Lok II
Union Corrugating Company	SL150
Union Corrugating Company	ML150
Union Corrugating Company	Guardian 1 / II / Lok
Union Corrugating Company	Sure-Lok / Supreme-Lok
Varco Pruden	SSR
Varco Pruden	HWR
Varco Pruden	SLR
Vic West	Prestige
Vic West	Tradition-100
Vic West	TSR

FABRICANTE:**TIPO DE PANEL:**

Vic West	Tradition 150-4
Whirlwind Building Systems	Weather Lok-16
Whirlwind Building Systems	Weather Snap-16
Whirlwind Building Systems	Super Seam II/Super Seam Plus
Zamil Steel Industries	Max Seam
Zimmerman Metals, Inc.	SL-1500, SL1750, SLC1000
Zimmerman Metals, Inc.	SS1500, SS2000, SS2500, TSS2500

► **18.0 FORMULARIO DE INSPECCIÓN ANUAL DE SAFEWAZE**

Fecha de inspección:	Inspector:	Aprobada/ Desaprobada:  	Comentarios/ Medida correctiva:
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	
		 	

Dirección: 225 Wilshire Ave SW, Concord, NC 28025

Teléfono: (800) 230-0319

Fax: 704-262-9051

Correo electrónico: info@safewaze.com

Sitio web: safewaze.com